

1 Lecture 17

Slide 1

Mode-locking

The **Q-switch** mode allows to obtain short pulses with very high intensity (peak photon number $\phi_P \approx 10^{17}$) but the **pulse duration** is of the order of a few ns:

$$\Delta\tau_p = \eta_E \tau_c \frac{x}{x - 1 - \ln(x)} \propto \tau_c$$

A technique that allows to obtain ultra-short pulses, down to 5 fs, is:

Mode-locking This is obtained combining in phase (mode-locking) a given (large) number of different longitudinal modes with different frequencies.

when the modes of an em wave with different frequencies are combined in phase, they give rise to an electric field with amplitude and intensity with a characteristic repetitive nature

333

Slide 2

Mode-locking

when the modes of an em wave with different frequencies but random phases are added up they give rise to an electric field with amplitude and intensity randomly distributed in the time domain.

Mode-locking This is obtained combining in phase (mode-locking) a given (large) number of different longitudinal modes with different frequencies.

when the modes of an em wave with different frequencies are combined in phase, they give rise to an electric field with amplitude and intensity with a characteristic repetitive nature

334

Slide 3

Mode-locking

The longitudinal modes of a laser cavity are separated in frequency by:

$$\Delta\nu_{sep} = \frac{c}{2L_e}$$

If the gain bandwidth is larger than $\Delta\nu_{sep}$ it is possible to have more than one longitudinal mode oscillating in the cavity

$E(t) = E_m e^{i(\omega_m t + \phi_m)}$ Electric field amplitude of the m-th mode

Let's assume that N modes with the same amplitude E_0 are oscillating at the same time in the laser cavity. The total amplitude of the resulting field will be:

$$E(t) = E_0 \sum_{m=0}^{N-1} e^{i(\omega_m t + \phi_m)} \quad \omega_{m+1} - \omega_m = \Delta\omega = 2\pi\Delta\nu_{sep} = \frac{\pi c}{L_e}$$

335

Is there a technique to obtain ultra-short pulses of the order of fs? It is **mode-locking**.

The basic idea is to lock in phase a large number of longitudinal modes. We obtain pulses with a given pulse duration and with a temporal separation.

It is different if we combine modes with random phases. We do not obtain a repetitive nature of the electric field but spike as shown here.

Instead, for mode-locking we combine in phase the modes. We will see that the larger is the number of the modes, the shorter is the pulse duration that we can obtain.

Let us consider to have different **longitudinal modes** oscillating in the cavity and with a frequency separation $\Delta\nu_{sep}$.

If we do not do anything we have several longitudinal mode with a bandwidth which is the bandwidth of the gain of the medium.

$E(t)$ is the electric field amplitude of the m-th mode. Let us assume to simplify the problem and suppose we are able to have N modes with the same amplitude and oscillating at the same time in the laser cavity.

The total amplitude of the electric field in the cavity is given by the sum of all these nodes.

The difference in terms of angular frequency is $2\pi\Delta\nu_{sep}$.

Slide 4

800 ANNI UNIVERSITÀ DEGLI STUDI DI PADOVA Mode-locking Optics and Laser Physics T. Cesca

If the modes oscillate with **random phases** (and the number is sufficiently large) the total intensity results (on average the mixed terms cancel out):

$$I(t) \propto |E(t)|^2 = E_0^2 \sum_{m=0}^{N-1} e^{i(\omega_m t + \phi_m)} e^{-i(\omega_m t + \phi_m)} = N E_0^2 \propto NI_0$$

Let's see what happens if we make the modes oscillate **in phase** (i.e., if they are **mode-locked**):

$$\phi_m = \phi_0, \forall m \quad E(t) = E_0 \sum_{m=0}^{N-1} e^{i(\omega_m t + \phi_0)} = E_0 e^{i\phi_0} \sum_{m=0}^{N-1} e^{i\omega_m t}$$

Defining $\omega_m = \omega_0 + m\Delta\omega$

$$E(t) = E_0 e^{i\phi_0} \sum_{m=0}^{N-1} e^{i(\omega_0 + m\Delta\omega)t} = E_0 e^{i(\omega_0 t + \phi_0)} \sum_{m=0}^{N-1} e^{i(m\Delta\omega)t}$$

336

Slide 5

800 ANNI UNIVERSITÀ DEGLI STUDI DI PADOVA Mode-locking Optics and Laser Physics T. Cesca

$$\begin{aligned} E(t) &= E_0 e^{i\phi_0} \sum_{m=0}^{N-1} e^{i(\omega_0 + m\Delta\omega)t} = E_0 e^{i(\omega_0 t + \phi_0)} \sum_{m=0}^{N-1} e^{i(m\Delta\omega)t} = \\ &= E_0 e^{i(\omega_0 t + \phi_0)} [1 + e^{i\Delta\omega t} + e^{2i\Delta\omega t} + \dots] \\ &= E_0 e^{i(\omega_0 t + \phi_0)} \left[\frac{1 - e^{iN\Delta\omega t}}{1 - e^{i\Delta\omega t}} \right] \quad 1 - \cos(\vartheta) = 2\sin^2\left(\frac{\vartheta}{2}\right) \end{aligned}$$

$$I(t) \propto |E(t)|^2 = E_0^2 \left| \frac{1 - e^{iN\Delta\omega t}}{1 - e^{i\Delta\omega t}} \right|^2 = E_0^2 \frac{\sin^2\left(\frac{N\Delta\omega t}{2}\right)}{\sin^2\left(\frac{\Delta\omega t}{2}\right)} \propto I_0 \frac{\sin^2\left(\frac{N\Delta\omega t}{2}\right)}{\sin^2\left(\frac{\Delta\omega t}{2}\right)}$$

N-slits interference!

337

Slide 6

800 ANNI UNIVERSITÀ DEGLI STUDI DI PADOVA Mode-locking Optics and Laser Physics T. Cesca

$$I(t) = I_0 \frac{\sin^2\left(\frac{N\Delta\omega t}{2}\right)}{\sin^2\left(\frac{\Delta\omega t}{2}\right)}$$

$$\text{Maxima (Den = 0)} \quad \frac{\Delta\omega t}{2} = m\pi \quad \Rightarrow \quad t_{MAX} = \frac{m2\pi}{\Delta\omega}$$

$$I(t_{MAX}) = N^2 I_0$$

time needed to make a complete lap of the cavity (back and forth)

$$\Delta t_{sep} = \frac{2\pi}{\Delta\omega} = \frac{1}{\Delta\nu_{sep}} = \frac{2L_e}{c} \quad \text{temporal difference between two consecutive maxima}$$

338

If these modes oscillates with **random phases** and if the number of nodes is sufficiently large, when we calculate the intensity we obtain that it is proportional to NI_0 . If the modes oscillates in **phase** (so if we mode lock the modes). We assume that all the phases for each m we have Φ_0 .

The intensity is given now by this expression which reminds the equations which describe interference. Since the modes are locked in phase, we are having them interfering constructively. We obtain a figure of interference in the time domain!

Let us see how to calculate the most relevant parameter. To calculate Δt_{sep} , we need to calculate at which time we get a maximum: when the denominator goes to zero. The intensity of the peak is proportional to N^2 , the square value of the number of modes you are locking in phase.

Slide 7

Mode-locking

$I(t) = I_0 \frac{\sin^2\left(\frac{N\Delta\omega t}{2}\right)}{\sin^2\left(\frac{\Delta\omega t}{2}\right)}$

Minima (Num = 0) $\frac{N\Delta\omega t}{2} = m\pi \Rightarrow t_{min} = \frac{m2\pi}{N\Delta\omega}$

The pulse width ($\Delta\tau_p$) is given by the temporal separation between two minima around a maximum

$$\Delta\tau_p = \frac{2\pi}{N\Delta\omega} = \frac{1}{N\Delta\nu_{sep}} = \frac{1}{\Delta\nu_0}$$

gain bandwidth

The width of the gain curve determines the pulse duration: the larger the gain bandwidth, the shorter the pulse duration.

339

Slide 8

Nd lasers

Property	Nd:YAG	Nd:glass
Nd doping	1 % at.	3.8 wt. % (Nd_2O_3)
Nd ³⁺ concentration	N_t	1.38×10^{20} ions/cm ³
Wavelength	λ	1.064 μm
Upper laser level lifetime	τ	230 μs
Linewidth	$\Delta\nu_0$	4.0 cm ⁻¹ (~120 GHz)
Stimulated emission cross-section	σ_e	2.8×10^{-19} cm ²
Refractive index	n	1.82
		1.54

340

To calculate the temporal duration $\Delta\tau_p$, we compute the difference in time between the position of two minima around one maximum.

$N\Delta\nu_{sep}$ is equal to the $\Delta\nu_0$, which is the **gain bandwidth** (since you obtain gain only for the nodes in the gain bandwidth).

The larger is the gain bandwidth, the shorter is the pulse duration. So, to realize ultra fast pulses you need to work with active media with large bandwidth.

Slide 9


Ti:Al₂O₃ laser

Proprietà	valore	
Ti ³⁺ concentration	N_t	
Wavelength	λ	660-1180 nm
Upper laser level lifetime	τ	3.8 μs
Linewidth	$\Delta\nu_0$	100 THz
Stimulated emission cross-section	σ_e	3.4×10^{-19} cm ²
Refractive index	n	1.76

341


It is the typical laser to obtain pulsed operation. It has a very very larg bandwidth!

Slide 10



342

Slide 11




343

If the pulse is sufficiently intense, it will open the shutter. So, it is the material itself which know when to open. In particular, **passive shutters are typically faster than active ones**.

So, we need some noise to trigger the shutter opening. A spike intensity at the beginning open the shutter. From that time, when a peak arrive it will open the shutter.

(?)

Slide 12



344

With He-Ne laser we obtain a much longer pulse duration.

The basic idea of mode-locking is to lock in phase a large number of modes and to have them you have a large bandwidth in our active medium: the larger is the bandwidth the shorter is the pulse duration!

The question now is how it is possible to lock in phase different longitudinal modes experimentally?

We use an **optical shutter** in the cavity that we are able to control. When the shutter is open, all the electric fields of all the modes will be maximize (opening the shutter means reducing losses in the cavity for all the modes in the cavity) at the same time.

An **active shutter** is an electro-optic device. It has the drawback to open exactly the shutter each time the pulse arrive in the shutter itself. You have to be very carefull in controlling the moments in which you open the shutter. A **passive shutter** is a non-linear optical element. In particular it is a material which is able to work as a *saturable absorber*. It becomes transparent to radiation if the intensity of the beam is larger than the saturation intensity, in particular it has a **low saturation intensity**!

The position at which you place the shutter is important: you need to have a shutter which opens every time a pulse is arriving on it (independently on active or passive shutter).


If the separation in time is given $2L/c$, which correspond to the situation in which a pulse is making a complete pass back and forth within the cavity. This separation means that the shutter has to be placed exactly at the position of one of the two mirrors. For all the other modes, they will find the shutter close.

It is possible to select other configuration, as for instance with a time separation of L/c . In this case the shutter is in the middle of the cavity.

For an active shutter you need to open the shutter when the pulse arrive.

The last configuration is for a ring cavity for which the position of the shutter is irrelevant! That is why ring cavities are useful.


Slide 13



345

This is a photon of Nd:YAG mode-locking.
The shutter is at the position of the mirror 1.
There is not only the **oscillator** part, but also the **amplifier**.


Slide 14



346

Hence, in mode-locking we obtain a train of pulses.

Slide 15



347

It is an example of a ring cavity laser operating in mode-locking. The separation in time is of about 5 ns with a pulse duration of 0.2 ps. The rod is placed at the Brewster angle to minimize the losses in reflection at the edges of the rod.

Slide 16



Mode-locking

*Optics and
Laser Physics
T. Cesca*

Compute the mode-locked pulse width $\Delta\tau_p$ and the separation between pulses Δt_{sep} for the following mode-locked lasers:

- A He-Ne laser operating at 632.8 nm, with a mirror cavity spacing of $L = 0.5 \text{ m}$
- A Rh6G dye laser operating over its entire gain bandwidth (570-640 nm) with the cavity mirrors separated by 2 m. The index of refraction of a laser dye in a typical solvent is approximately 1.4

a.

For He-Ne we can assume a refractive index $n \cong 1 \implies L_e = L = 0.5 \text{ m}$

$$\Delta t_{sep} = \frac{2L_e}{c} \cong \frac{2 \cdot 0.5 \text{ m}}{3 \cdot 10^8 \frac{\text{m}}{\text{s}}} \cong 3.3 \text{ ns}$$

$$\Delta\nu_0 \cong 1.5 \text{ GHz}$$

$$\Delta\tau_p = \frac{1}{\Delta\nu_0} \cong \frac{1}{1.5 \text{ GHz}} \cong 6.67 \cdot 10^{-10} \text{ s} \cong 667 \text{ ps}$$

Doppler broadening
(inhomogeneous)

Let us make an exercise about the mode-locking.
For He-Ne we can assume $n = 1$!

348

Slide 17



Mode-locking

*Optics and
Laser Physics
T. Cesca*

Compute the mode-locked pulse width $\Delta\tau_p$ and the separation between pulses Δt_{sep} for the following mode-locked lasers:

- A He-Ne laser operating at 632.8 nm, with a mirror cavity spacing of $L = 0.5 \text{ m}$
- A Rh6G dye laser operating over its entire gain bandwidth (570-640 nm) with the cavity mirrors separated by 2 m. The index of refraction of a laser dye in a typical solvent is approximately 1.4

b.

We can neglect the dye cell thickness with respect to the entire cavity length

$$\Rightarrow L_e = L = 2 \text{ m} \quad \Delta t_{sep} = \frac{2L_e}{c} \cong \frac{2 \cdot 2 \text{ m}}{3 \cdot 10^8 \frac{\text{m}}{\text{s}}} \cong 1.33 \cdot 10^{-8} \text{ s} \cong 13.3 \text{ ns}$$

$$\Delta\nu_0 = \frac{c}{\lambda^2} \Delta\lambda \cong \frac{3 \cdot 10^8 \frac{\text{m}}{\text{s}}}{(605 \text{ nm})^2} (70 \text{ nm}) \cong 5.7 \cdot 10^{13} \cong 57 \text{ THz}$$

$$\Delta\tau_p = \frac{1}{\Delta\nu_0} \cong \frac{1}{57 \text{ THz}} \cong 1.75 \cdot 10^{-14} \text{ s} \cong 17.5 \text{ fs}$$

We can neglect the presence of the cell even it has a larger refractive index wrt the environment because the thickness is very low.

349